

## LANCOM WiFi & 4G Routers

AirLancer Antenna	1780EW-4G Connector: Reverse-SMA-Jack / SMA-Jack	1781A-4G Connector: SMA-Jack	1781EW+ Connector: Reverse-SMA-Jack	1781AW Connector: Reverse-SMA-Jack	1781-4G Connector: SMA-Jack	1781VA-4G Connector: SMA-Jack	1783VA-4G Connector: SMA-Jack	1781VAW Connector: Reverse-SMA-Jack	1783VAW Connector: Reverse-SMA-Jack
ON-T360ag/ON-Q360ag Connector: N-Jack	With adaptor cable AirLancer AN-RPSMA-NJ		With adaptor cable AirLancer AN-RPSMA-NJ	With adaptor cable AirLancer AN-RPSMA-NJ				With adaptor cable AirLancer AN-RPSMA-NJ	With adaptor cable AirLancer AN-RPSMA-NJ
ON-T60ag/ON-Q60ag Connector: N-Jack	With adaptor cable AirLancer AN-RPSMA-NJ		With adaptor cable AirLancer AN-RPSMA-NJ	With adaptor cable AirLancer AN-RPSMA-NJ				With adaptor cable AirLancer AN-RPSMA-NJ	With adaptor cable AirLancer AN-RPSMA-NJ
ON-T90ag/ON-Q90ag Connector: N-Jack	With adaptor cable AirLancer AN-RPSMA-NJ		With adaptor cable AirLancer AN-RPSMA-NJ	With adaptor cable AirLancer AN-RPSMA-NJ				With adaptor cable AirLancer AN-RPSMA-NJ	With adaptor cable AirLancer AN-RPSMA-NJ
ON-360ag Connector: N-Jack	With adaptor cable AirLancer AN-RPSMA-NJ		With adaptor cable AirLancer AN-RPSMA-NJ	With adaptor cable AirLancer AN-RPSMA-NJ				With adaptor cable AirLancer AN-RPSMA-NJ	With adaptor cable AirLancer AN-RPSMA-NJ
O-30 Connector: N-Jack	With antenna enclosed adaptor cable AirLancer RP-SMA Plug / N Plug		With antenna enclosed adaptor cable AirLancer RP-SMA Plug / N Plug	With antenna enclosed adaptor cable AirLancer RP-SMA Plug / N Plug				With antenna enclosed adaptor cable AirLancer RP-SMA Plug / N Plug	With antenna enclosed adaptor cable AirLancer RP-SMA Plug / N Plug
O-D9a Connector: N-Jack	With antenna enclosed adaptor cable AirLancer RP-SMA Plug / N Plug		With antenna enclosed adaptor cable AirLancer RP-SMA Plug / N Plug	With antenna enclosed adaptor cable AirLancer RP-SMA Plug / N Plug				With antenna enclosed adaptor cable AirLancer RP-SMA Plug / N Plug	With antenna enclosed adaptor cable AirLancer RP-SMA Plug / N Plug
O-9a Connector: N-Jack	With antenna enclosed adaptor cable AirLancer RP-SMA Plug / N Plug		With antenna enclosed adaptor cable AirLancer RP-SMA Plug / N Plug	With antenna enclosed adaptor cable AirLancer RP-SMA Plug / N Plug				With antenna enclosed adaptor cable AirLancer RP-SMA Plug / N Plug	With antenna enclosed adaptor cable AirLancer RP-SMA Plug / N Plug
O-18a Connector: N-jack	With antenna enclosed adaptor cable AirLancer RP-SMA Plug / N Plug		With antenna enclosed adaptor cable AirLancer RP-SMA Plug / N Plug	With antenna enclosed adaptor cable AirLancer RP-SMA Plug / N Plug				With antenna enclosed adaptor cable AirLancer RP-SMA Plug / N Plug	With antenna enclosed adaptor cable AirLancer RP-SMA Plug / N Plug
O-360-4G Connector: SMA-Plug	No adaptor required	No adaptor required			No adaptor required	No adaptor required	No adaptor required		
IN-T180ag Connector: Reverse-SMA-Plug	No adaptor required	No adaptor required			No adaptor required	No adaptor required	No adaptor required		
I-60ag Connector: Reverse-SMA-Plug	No adaptor required		No adaptor required	No adaptor required				No adaptor required	No adaptor required
I-360-3G Connector: Reverse-SMA-Plug	No adaptor required	No adaptor required		No adaptor required	No adaptor required	No adaptor required	No adaptor required		
I-360-4G Connector: Reverse-SMA-Plug	No adaptor required	No adaptor required		No adaptor required	No adaptor required	No adaptor required	No adaptor required		

matching adaptor / cable must be purchased

matching adaptor / cable enclosed with access point or antenna

no adaptor required